




## Table of Contents

<b>1.0</b>	<b>Shifter Overview .....</b>	<b>3</b>
<b>2.0</b>	<b>Basic Safety .....</b>	<b>5</b>
<b>3.0</b>	<b>Installation .....</b>	<b>6</b>
3.1	Factory shifter removal .....	6
3.2	KinematicSpeed race shifter installation .....	10
<b>4.0</b>	<b>Setup and Testing .....</b>	<b>13</b>
4.1	Adjusting centering position .....	13
4.2	Setting side travel stops .....	14
4.3	Testing function.....	15


## 1.0 Shifter Overview

**For installation and setup the following features of the shifter will be used or adjusted:**

- Rear sliding mount bolt (1 of 3 total mounting bolts to secure shifter to chassis)
- Front driver and passenger side mount bolts (2 of 3 total mounting bolts to secure shifter to chassis)
- Side travel stop for the 5<sup>th</sup> and 6<sup>th</sup> gear gate
- Side travel stop for the Reverse gear gate
- Centering adjustment bolt (DO NOT REMOVE)
- Selector Rod attachment point (choice of two attachments for short or long throw)
- Knob securing bolt (if removing knob to install shift boot)



(Figure 1)




(Figure 2)



(Figure 3)

The installation orientation can be seen in the following figure 4:



(Figure 4)

## 2.0 Basic Safety

Prior to working on vehicle, properly raise on lift or jack stands and secure safely. Disconnect negative battery terminal if interfacing with electrical connections and or wiring. Installation of the race shifter requires a strong level of mechanical competency, when in doubt please consult your local mechanic/race shop and entrust installation to a trained professional.

## 3.0 Installation

### 3.1 Factory shifter removal

- Shift transmission into neutral (this aids in disconnection/connection of the selector rod)
- Remove factory shift knob by firmly grasping and pulling directly up.




- Remove factory interior boot by gently prying at edges of plastic securing ring to disengage snaps from console. Slide boot up and over shift shaft to remove.



- Remove all interior foam and sound deadening from within shifter console.
- Gently work factory rubber shift boot out of transmission tunnel hole and slide up and over shift shaft to remove.




- Move to underneath car. Removal of exhaust is optional and can gain clearance to remove factory shifter but job can be completed with exhaust in place.
- Remove selector rod to shift lever securing clip, do not disregard this clip or plastic shim washers.



- Disconnect selector rod from shift lever.



- Remove securing pin holding shifting arm to transmission. (Lowering the transmission slightly can help gain access, be sure to properly support transmission during this and be mindful to not damage motor mounts).



- Remove shifting arm and shift lever assembly by sliding shifting arm forward and out of rear rubber bushing mount on body.




- Remove factory shifter assembly from car.

### 3.2 KinematicSpeed race shifter installation


- Locate factory square hole just rearward of transmission tunnel shifter hole. Often this is covered in butyl tape, remove tape and clean surface. (This will be used to secure the shifter's rear sliding bolt)



- Remove the two front mounting bolts from the shifter by removing the thin locknuts that secure the front mounting bolts and remove bolts from base.



- Ensure the rear sliding bolt thin locknut is loose so bolt can slide through its full range of motion in the slot in the cast shifter base.



- Position shifter in car by guiding rear sliding bolt into factory square rear hole in unibody and centering shifter left to right on transmission tunnel. Use travel in rear sliding bolt to best center shifter over shifter hole in transmission tunnel.



- Utilizing a punch or paint pen – mark the unibody through the front mount holes in the cast base to identify where to drill the two front mounting holes for the shifter.




- Remove the shifter and drill both holes using a 1/4" drill bit. Verify holes align with shifter base following drilling.
- Reinstall front shifter bolts with thin locknuts in base to facilitate one person installation.



- Reinstall shifter in all three holes in unibody guiding shifter bolts through holes.

- Secure shifter from underneath car with supplied washers and nylock nuts. Tighten nylock nuts to 84-94 inlbs.




**TORQUE TO 84-94 INLBS**

- Connect selector rod to attachment hole on bottom of shifter utilizing factory plastic shim washers as needed to take up clearance in joint. **We recommend utilizing the lower hole for best performance in E36 applications.**

## 4.0 Setup and Testing

### 4.1 Adjusting centering position


- Returning to inside the car – shift car into 3<sup>rd</sup> gear.
- Utilizing 10mm open end wrench – loosen (DO NOT REMOVE) shifter centering bolt so bolt can slide laterally in slot.




- Hold shifter in center of 3<sup>rd</sup> gear gate and tighten centering bolt. This effectively aligns the shifter's center position with the center of the transmission's 3<sup>rd</sup> and 4<sup>th</sup> gear gate. **THIS IS A CRITICAL STEP IN SETTING UP THE SHIFTER TO ENSURE PEAK PERFORMANCE IN YOUR APPLICATION. PLEASE TAKE CARE TO ENSURE SHIFTER IS CENTERED ON CENTER OF 3<sup>RD</sup> GEAR GATE.** (to test centering setting, push shifter side to side when in 3<sup>rd</sup> gear and ensure the side to side travel while in gear is equal in both directions – if unequal – repeat adjustment procedure.)

#### 4.2 Setting side travel stops

- Set 5<sup>th</sup>/6<sup>th</sup> gear stop – start by shifting transmission into 5<sup>th</sup> gear.
- Apply pressure to shift knob in passenger direction holding shifter against passenger side of 5<sup>th</sup> gear gate.
- Utilizing 3mm allen wrench – (continue to hold shifter against passenger side of 5<sup>th</sup> gear gate) tighten 5<sup>th</sup>/6<sup>th</sup> stop screw until light contact with the stop surface internal to the shifter is felt. (An adjustable threadlocker has been pre-applied to the stop screws, this will provide resistance as stop screw is adjusted inward and is normal. This ensures the screws are adjustable, but do not loosen during use)



- Set Reverse side travel stop – shift transmission into reverse.
- Apply pressure to shift knob in driver side direction holding shifter against driver side of reverse gate.
- Utilizing 3mm allen wrench – (continue to hold shifter against driver side of reverse gear gate) tighten reverse stop screw until light contact with the stop surface internal to the shifter is felt.



## 4.3 Testing function

- With car on lift shift through all gears. Ensure shifter centering position is properly centered on 3<sup>rd</sup>/4<sup>th</sup> gate. Ensure side travel stops are set such that they do not impede

- shifting into 5<sup>th</sup>/6<sup>th</sup> or reverse. (it is normal for a gear to occasionally not engage smoothly with car not running)
- Reassemble all exhaust and under panels (if removed).
  - Test drive vehicle to ensure proper function. (recommend leaving interior console pieces out until after test drive in case centering position or side travel stops need adjustment following test drive.)

**HAPPY SHIFTING!**